

Unleash Your Padelshooter

A Guided Journey from Your First Shot to Designing Pro-Level Drills



Your Path to App Mastery

1.



Master the Basics

Get started instantly with the simple and intuitive 'Start Here' screen.

2.



Elevate Your Training

Explore advanced, pre-set drills and combination shots in the 'Trainings' screen. ↘

3.



Design Your Drills

Become the architect of your own practice sessions by creating custom sequences in the 'Programs' screen. ↘

4.



Fine-Tune & Optimize

Unlock pro-level control and positioning with the 'Settings' screen. %

Your Control Panel: The Fundamentals

Getting Connected

1. Turn ON the Padelshooter machine.
2. Start the app on your phone/tablet.
3. Wait for the Bluetooth icon in the bottom right corner to turn green.



Understanding the Parameters

Speed (0-100): Controls the ball's velocity.

Spin (-50 to +50): Sets backspin (-), topspin (+), or no spin (0).

Freq (0-100): Sets the pause between balls (0=slowest, 100=fastest).

Width (0-100): Controls the horizontal placement or area.

Height (0-100): Sets the vertical trajectory of the ball.


Net (0-100): Defines the *minimum* height for any shot, preventing balls from hitting the net.



Remember: You can change values by 1 with a short press, or by 10 with a long press on the arrows.

Step 1: Master the Basics with 'Start Here'

The 'Start Here' screen is designed for simplicity and immediate action. It's the perfect way to get familiar with your **Padelshooter** using single-shot trainings. Simply tap a training icon, adjust your settings, and press **Play**.



Select your drill.

Choose your side of the court:
Left, Right, or Both.

Fine-tune your Control Panel.


Start the session.

Decoding 'Start Here': Your First Drills




Fixed

Practice a consistent shot to one location. Use **Width** to set the horizontal position.




Vert movement

Practice reacting to different depths. Shoots to a single horizontal spot but at random heights between the **Net** (lowest) and **Height** (highest) settings.




Hor movement

Train your lateral movement with balls at random horizontal positions but a consistent depth. **Width** controls the size of the random area.



Random

The ultimate reaction drill. Shoots balls at random horizontal *and* vertical positions.



2-Line

Ideal for two players or for practicing forehand/backhand switches. Shoots to two exact positions. **Width** sets the distance between them.



For any training with random height (like 'Vert movement' or 'Random'), if balls are going into the net, increase the 'Net' value. The machine will never shoot lower than this setting.

Decoding 'Start Here': Padel-Specific Shots




Bandeja / Smash

Practice your overheads. **Height** sets the loft. Use a higher **Speed** for a deeper bandeja and a lower **Speed** for a smash closer to the net.



Bajada

A high ball with topspin designed to bounce high off the back glass, setting you up for a bajada. The settings are critical; adjust **Speed** if the ball bounces incorrectly.



Volley

Shoots randomly to three positions: left, middle, right (backhand, body, forehand). **Width** controls the distance between these shots.



Backglass


A high-speed ball that bounces just before the back glass. Increase the difficulty by using backspin (**Spin** < 0).

Step 2: Elevate Your Game with 'Trainings'

Ready for more? The 'Trainings' screen introduces combination drills and gives you more precise control over the court. This is where you start training for realistic match scenarios.



Precision Targeting: Instead of just Left/Right, you can now define the exact horizontal court area to train in using **Left %** and **Right %**.



Combination Shots: Practice sequences of different shots, like a **volley** followed by a **bandeja**.



New Parameter: Delay (0-100): Add an extra pause (up to 2 seconds) *only* after high balls. This is crucial for giving you time to recover after a **bandeja** before the next **volley** comes.

Master Combination Drills

When you see an 'x' in a drill name (e.g., 'x Volleys'), it means a random number of those shots will be played, from 1 to 10.

Volley - Bandeja Series



Volley - Bandeja: Alternates one volley and one bandeja continuously.

x Volleys - 1 Bandeja: Drills volleys with an occasional high ball.

1 Volley - x Bandejas: Drills bandejas with an occasional volley to keep you on your toes.

x Volleys - x Bandejas: Fully random sequence of volleys and bandejas.

Cross 1 & 2



Cross 1: Low ball to the left, high ball to the right.

Cross 2: High ball to the left, low ball to the right.

Pro-Tip: For all mixed drills: Use `Net` to set the volley height, `Height` for the bandeja height, and `De'lay` to add a pause after the bandeja. This is the key to realistic timing!

Step 3: Design Your Signature Drills

The “Programs” screen transforms you from a trainee into a training designer. Here you can build custom sequences of up to 20 shots from scratch, save them, and perfect the exact drills you need to work on.

Name & organize your drills.

Build your sequence, shot by shot.

The image displays two screenshots of a mobile application interface for designing drills. The left screenshot shows the 'Programs' screen with a list of drills, including 'Right-Mixed-Volleys' and 'Left-Mixed-Volleys'. Each drill has a sequence of shots, with parameters like Speed, Spin, Freq, Width, and Height. The right screenshot shows a detailed view of a single shot (Shot 1) with parameters like Speed, Spin, Freq, Width, and Height, and buttons for 'Add Shot', 'Save Program', 'Load Program', 'Play Program', 'Delete Shot', and 'Copy Shot'.

Set unique parameters for every single ball.

Building Your First Program: A Step-by-Step Guide




1. Start Fresh

Press 'Reset' to clear any existing program.



2. Name Your Drill

Type a descriptive name in the 'Program Name' field and select or create a 'Category'.



3. Add Your First Shot

Press 'Add Shot' and set the five parameters (Speed, Spin, Freq, Width, Height) for your first ball.



4. Build the Sequence

Press 'Add Shot' for each new ball in your sequence.



Time-Saver Tip: Select an existing shot and press 'Copy Shot' to duplicate it. Then, you only need to change one or two parameters (e.g., just the 'Width') for the next ball in the sequence.



5. Adjust the Order

Select a shot and use 'Move Up' or 'Move Down' to change its position in the sequence.




6. Save & Play

Once you're done, press 'Save Program'. To run it, select it from the list and press 'Play Program'.

Step 4: Fine-Tune Your Machine & App

The 'Settings' screen is where you optimize your entire setup. Here you can customize the app, manage your training data, and use powerful tools to position your Padelshooter for maximum court coverage.



App Customization

Choose your language and switch between Padel and Tennis speed modes.



Data Management

Import and export your custom settings and programs.



Machine Positioning

Tools to help you perfectly align the machine on the court.

Optimize with Settings & Programs



Get the “Perfect” Settings

“Import Settings from Web”

When you first install the app, it loads optimal settings for every drill. If you've changed things and want to return to the recommended defaults, use this button. It's your 'factory reset' for peak performance. (Requires internet).



Download Pro Drills

“Import Programs from Web”

Instantly load your app with ready-made training programs from the Padelshooter website. A great way to discover new drills. (Requires internet).



Backup & Share Your Work

“Export/Import Settings”


“Export/Import Programs”

Save your custom settings and programs to a file on your phone. This is perfect for backing up your work or sharing your favorite drills with other Padelshooter owners.

Pro-Tip: Master Your Machine Positioning


1. The Standard Center

Place the machine at the back glass, in the horizontal middle. Press the 'Middle' button in Settings. The ball should bounce on the center service line. Adjust the machine until it does.




2. Optimize for One Side

Move the machine physically towards the right side. Press the 'Right' button. Reposition until this test shot lands on the center line. Now, your drills will cover the right side and side wall more effectively.



3. The Realistic Match Position

Place the machine in one corner, aimed towards the opposite corner. This simulates a cross-court rally and is excellent for training shots involving both the side and back walls.



You're in Control

You've journeyed from the simple "Start Here" screen to designing your own professional drills. You now have the knowledge to control every aspect of your training, from the spin on a single ball to the precise position of the machine on the court.

Now, go create the practice you need to win the points you want. Your court awaits.

